

KT-502H

Features

- HART protocol
- 330° rotatable display for environment conditions
- 4-20 mA analog output (2-wire)
- Various input
 - RTD: 8 types, Thermocouple: 8 types,
 - mV: 4 types, Ω : 2 types
- Backlight helps to read easily in the darkness
- Explosion-proof structure : Ex d IIC T6(IP67)



Please read "Caution for your safety" in operation manual before using this unit.



Ordering information

KT

502H

0

Mounting bracket

0

Without bracket

1

With bracket



Specifications

Model	KT-502H		
Power supply	10.5-45VDC (with backlight LCD)		
Display method	PV display part : 7 Segment 5 digit (character size : W4×H8mm) Parameter display part : 14 Segment 8 digit (character size : W2.6×H4.8mm) 52 Bar meter		
Display range	-19999 to 99999		
Setting method	HART-protocol (no setting key)		
Response time	1 sec.		
Input type and accuracy	Type	Measuring accuracy	
	RTD	DPT100 Ω , Ni100 Ω	0.2K or 0.08%
		DPT500 Ω , Ni500 Ω	0.5K or 0.20%
		DPT1000 Ω , Ni1000 Ω	0.3K or 0.12%
		Cu50 Ω	0.2K or 0.08%
		Cu100 Ω	0.3K or 0.12%
	Thermocouple	K, J, T, E	typ.0.5K or 0.08%
		N	typ.1.0K or 0.08%
		S, B, R	typ.2.0K or 0.08%
	Resistance tran. (Ω)	0 to 400 Ω	\pm 0.1 Ω or 0.08%
0 to 2000 Ω		\pm 1.5 Ω or 0.12%	
Voltage trans. (mV)	-10-75 mV	\pm 20 μ V or 0.08%	
	-100-100 mV	\pm 0 μ V or 0.08%	
	-100-500 mV	\pm 0 μ V or 0.08%	
	-100-2000 mV	\pm 0 μ V or 0.08%	
Output	4-20 mA(2-wire)		
Alarm	Below 3.8 mA, Over 20.5 mA Sensor break 3.6mA		
Load	max.(V power supply - 7.5V)/0.22A		
Galvanic insulation	2KVAC(input/output)		
Environment	Ambient temperature	-20 to 70 °C, storage: 20 to 80 °C	
	Ambient humidity	0 to 85%RH	
Explosion-proof structure	Ex d IIC T6(IP67)		
Material	Body : Aluminum(AlDc.8S), Cover O-Ring : Buna N		
Unit weight	Approx. 1.2 kg		



※ Environment resistance is rated at no freezing or condensation.

Intelligent Temperature Transmitter

Dimensions



• Mounting bracket




- A. Recorder
- B. Indicator
- C. Converter
- D. Controller
- E. Thyristor unit
- F. Temp. sensor
- G. Pressure transmitter
- H. Temp. transmitter
- I. Thermometer
- J. Pressure gauge
- K. Accessories


Input type and range

Input type		Input range(°C)	Input range(°F)
RTD	DPt100Ω	-200 to 850	-328 to 1562
	DPt500Ω	-200 to 250	-328 to 482
	DPt1000Ω	-200 to 250	-328 to 482
	Cu50Ω	-50 to 150	-58 to 302
	Cu100Ω	-50 to 150	-58 to 302
	Ni100Ω	-60 to 180	-76 to 356
	Ni500Ω	-60 to 180	-76 to 356
	Ni1000Ω	-60 to 150	-76 to 302
Resistance (Resistance transmitter)	Resistance (Ω)	0 to 400Ω 0 to 2000Ω	
	Thermocouple	B (PtRh30-PtRh6)	0 to 1820
E(NiCr-CuNi)		-270 to 1000	-454 to 1832
J(Fe-CuNi)		-210 to 1200	-346 to 2192
K(NiCr-Ni)		-270 to 1372	-454 to 2501
N(NiCrSi-NiSi)		-270 to 1300	-454 to 2372
R(PtRh13-Pt)		-50 to 1768	-58 to 3214.4
S(PtRh10-Pt)		-50 to 1768	-58 to 3214.4
T(Cu-CuNi)		-270 to 400	-454 to 752
Analog	Voltage	-10 - 75mV	
		-100 - 100mV	
		-100 - 500mV	
		-100 - 2000mV	

Connections



• Mounting bracket



To open the cover, unscrew the M3 X 6L headless bolt using a 1.5 hexagon wrench and rotate the cover.

KT-502H


CN-502H

Current Trim adjustment

- ① Select the '**1. Device Setup**' by ↑, ↓ keys and press the  key. .

```

1. Device Setup
2. PV
3. PV Ao
4. PV LRV
5. URV
    
```

- ② Select the '**2. Diag/Service**' by ↑, ↓ keys and press the  key.

```

1. Process Variables
2. Diag/Service
3. Basic Setup
4. Detailed Setup
5. Review
    
```

- ③ Select the '**4. D/A trim**' by ↑, ↓ keys and press the  key.

```

1. Test device
2. Loop test
3. Calibration
4. D/A trim
    
```

- ④ Press the  (F4) key.

```

WARN-Loop should be
removed from
automatic control
    
```

- ⑤ Press the  (F4) key.

```

Connect reference
meter
    
```

- ⑥ Press the  (F4) key.

```

Setting fid dev
output to 4mA
    
```



 


- ⑦ Press the  (F4) key to set 4 mA display value.

```

Enter meter Value
4.000
    
```

- ⑧ If output display value is correct, select '**1. Yes**' and press the  (F4) key. If not, select '**2. No**' and press the  (F4) key and re-set the display value.

Ex) If output display value is 3.89mA, select 3.89 and press the  (F4) key.

```

Fid dev output 4.000
mA equal to reference
meter ?
    
```

1. Yes

2. No

- ⑨ Press the  (F4) key.

```

Setting fid dev.
output to 20mA
    
```



 

- ⑩ Press the  (F4) key to set 20 mA display value.

```

Enter meter Value
20.000
    
```

- ⑪ If output display value is correct, select '**1. Yes**' and press the  (F4) key. If not, select '**2. No**' and press the  (F4) key and re-set the display value.

```

Fid dev output 20.000
mA equal to reference
meter ?
    
```

1. Yes

2. No

- ⑫ Press the  (F4) key.

```

NOTE-Loop may be
returned to automatic
control
    
```

- ⑬ Press the  (F3) key.

```

Diag/Service
1. Test device
2. Loop test
3. Calibration
4. D/A trim
    
```


  

- ⑭ Press the  (F3) key.

```

Device Disconnected
    
```

- ⑮ Press the  (F3) key to complete the adjustment.

```

1. Offline
2. Online
3. Frequency Device
4. Utility
    
```

Intelligent Temperature Transmitter


Temperature range setting

① Press the  key for 3 sec.

Select the '4. PV LRV' by \uparrow , \downarrow keys and press the  key.

```

Online (Generic)
1. Device Setup
2. PV
3. PV Ao
4. PV LRV
5. URV          SAVE
    
```

② Select '1. PV LRV'(Low temperature range) and press the  key.


```

1. PV LRV
2. URV
HELP  HOME
    
```

③ Set Low temperature range and press the **ENTER** (F4) key.

```

PV LRV
0.000 deg C
0.000
HELP  DEL  ESC  ENTER
    
```

④ Select '2. URV'(High temperature range) and press the  key.

```

1. PV LRV
2. URV
HELP  HOME
    
```

⑤ Set High temperature range and press the **ENTER** (F4) key.

```

PV URV
100.000 deg C
100.000
HELP  DEL  ESC  ENTER
    
```

⑥ When the set temperature range is correct, press the **SEND** (F2) key.

```

1. PV LRV 0.000 deg C
2. URV 100.000 deg C
HELP  SEND  HOME
    
```

⑦ Press the **OK** (F4) key.

```

- WARNING -
Pressing ' OK ' will
change device output
put 100P in manual
    
```

⑧ Press the **OK** (F4) key.

```

- WARNING -
Return control 100P
To automatic control
      OK
    
```

⑨ Check the set temperature range. Press the **HOME** (F3) key. HART communication is OFF.

```

1. PV LRV 0.000 deg C
2. URV 100.000 deg C
HELP  HOME
    
```

Proper usage

■ Caution for using

- For connecting the power, use a crimp terminal (M3.5, min. 7.2 mm).
- The connection of this unit should be separated from the power line and high voltage line in order to prevent inductive noise.
- Install a power switch or a circuit breaker to supply or cut off the power.
- Switch or circuit breaker should be installed nearby users for convenient control.
- Do not use this unit near the high frequency instruments (high frequency welding machine & sewing machine, large capacity SCR controller).
- Installation environment.
 - ① Indoor / Outdoor
 - ② Altitude max. 2,000 m
 - ③ Pollution degree 2
 - ④ Installation category II

A. Recorder

B. Indicator

C. Converter

D. Controller

E. Thyristor unit

F. Temp. sensor

G. Pressure transmitter

H. Temp. transmitter

I. Thermometer

J. Pressure gauge

K. Accessories

KT-502H

CN-502H